

## BOMBAY FORMULAS

**Base Formula:** Mix 1 gallon of water to 5 gallons of stain and mix thoroughly. Apply the stain with an airless sprayer using a 415 tip. One gallon will cover about 9 panels on one side. Formula for base is below.

SHERWIN-WILLIAMS 1667 03/30/18  
801-225-6630 Order# 0052200

INT/EXT ARCHITECTURAL  
COLORTOP SOLID STAIN  
STANDALONE

HC133 BOMBAY  
SHER-COLOR FORMULA

CCE*COLORANT	OZ	32	64	128
W1-White	6	12	-	1
B1-Black	-	13	1	1
R2-Maroon	-	4	-	-
Y3-Deep Gold	-	34	-	1

ONE GALLON DEEP  
20.102214 650711633

Non Returnable Tinted Color  
CAUTION: To assure consistent color,  
always order enough paint to complete  
the job and intermix all containers  
of the same color before application.  
Mixed colors may vary slightly from  
color strip or color chip.



0052200-004

1-3

**HIGHLIGHT FORMULAS:** Mix 1 quart of H&C to 1 gallon of water for the highlight colors. Use a sponge to apply highlights. Highlights are applied after the base. Mix often as solids will separate. Formulas for highlights are below.

SHERWIN-WILLIAMS 1667 03/30/18  
801-225-6630 Order# 0052200

INT/EXT ARCHITECTURAL  
COLORTOP SOLID STAIN  
STANDALONE

HC157 SANDSTONE  
SHER-COLOR FORMULA

CCE*COLORANT	OZ	32	64	128
W1-White	-	38	-	-
B1-Black	-	30	-	1
R2-Maroon	-	8	-	-
Y3-Deep Gold	-	52	-	-

ONE GALLON DEEP  
20.102214 650711633

Non Returnable Tinted Color  
CAUTION: To assure consistent color,  
always order enough paint to complete  
the job and intermix all containers  
of the same color before application.  
Mixed colors may vary slightly from  
color strip or color chip.



0052200-008

1-4